

1 Pump-Up of Main Wheel

General Information:

Because the valve is completely inside the aluminium rim, you need to use a valve extension to put air into the 20" Tyre.

Good quality bicycle pumps have been found best to pump air into the main wheel.

Please follow the listed steps:

1. Position your Glider in such a way, that the hidden valve is at the top of the rim.
2. Open the plastic cover (you do not need to disassemble the plastic cover, just open the top lids) and screw the valve extension onto the hidden valve.
3. Put approximately 4 bar pressure into the tyre. Because the main wheel is not carrying any weight except the weight of the glider, the pressure does not have to be accurate. You can put the pressure into the wheel by testing it the "old fashion way" by checking the pressure with your thumb. The maximum allowed pressure is shown on the tyre.
4. **ATTENTION:** do not forget to remove the valve extension prior to moving your easy-glider. The valve extension will damage your plastic covers if not removed.



ATTENTION:

The tyre and tube are standard BMX bicycle products and they can be purchased in any good bicycle shop. The dimension and specification is shown on the tyre.